



1-888-434-0888
TOLL FREE

ANGLE BARS

Table of Contents

Title:	Page
BARS AND COMPENSATORS	
Manual & Motorized Adjusting Shaft • Walk-In Type	<u>2</u>
Angle Bar Mounting Bracket Assembly	<u>3</u>
Compensators • Manual & Motorized	<u>4</u>
Notes Page	<u>5</u>
DRIVES	
Versa Bars • Metro & Metroliner	<u>6</u>
Drive Assembly • Cosmo & Regent	<u>7</u>
SLITTER SYSTEM	
Koegel Slitter Assembly	<u>8</u>
Stationary Slitter Roller • Walk-in Type	<u>9</u>
Stationary Slitter Roller • Cosmo & Regent	<u>10</u>
Slitter Roller • Manual Sidelay	<u>11</u>
Slitter Roller • Motorized Sidelay	<u>12</u>
Friction Slitter Assembly • Roller Front of Bars	<u>13</u>
Motorized Slitter Assembly	<u>14</u>
Slitter • Walk-in Type Angle Bars	<u>15</u>
Slitter Knife or Anvil	<u>16</u>
Slitter Scrapers	<u>17</u>
PNEUMATIC SYSTEM	
Friction & Motorized Slitter Assembly	<u>18</u>
ELECTRICAL SYSTEM	
Compensator • Operator Side	<u>19</u>
Compensator • Remote Control Box	<u>20</u>